

Instructions to establish communication between the parent and nursery unit (also called reconnecting or pairing)

Angelcare Sound Baby Monitor – AC420

1. Turn on the parent unit.
2. Turn on the nursery unit.
3. Normally the parent unit and nursery unit 'find' each other within seconds. The parent unit display will first show the channel of transmission (C1 to C8), which will be replaced by the room temperature and icons for all activated functions.

If this is not the case, please follow the following instructions:

1. Press the Channel Key (CH) on the parent unit once to enter Channel Selection Mode. The display should show '- -' and the 'In Range' icon will flash.
2. Press and hold the Channel Selector on the nursery unit (which is also the night light button) until the halo flashes.
3. You can now select the channel by pushing gently the Channel Selector button (also night light button) on the nursery unit. Every time you push this button, the channel number will go up one channel on the display of the parent unit.
4. Once you have selected a channel (C1 to C8), press and hold the Channel Selector button on the nursery unit to confirm the channel. The halo will stop flashing.
5. The parent unit and nursery unit are now on the same channel and sound transmission should be activated instantly.
6. If there is interference, repeat this process from step 1 and select another channel.

